


ECE 442

Solid-State Devices & Circuits

CMOS Process

Jose E. Schutt-Aine
Electrical & Computer Engineering
University of Illinois
jschutt@emlab.uiuc.edu

Basic Fabrication Process Chart



- **Clean Rooms**

- Semiconductor processing is performed in ultraclean facilities called clean rooms
- Sophisticated filtration to remove airbone particulates
- Workers must wear special uniforms to minimize introduction of contaminants

Clean Room Facility




CMOS Process Steps

- **Wafer Preparation**
 - Crystal orientation, doping, polishing
 - Typical wafers are 400 μm to 600 μm thick
- **Oxidation**
 - Silicon reacts with oxygen to form silicon dioxide SiO_2
 - Use high temperature (>1000 °C) to speed up process
 - SiO_2 is effective mask against impurities
- **Diffusion**
 - Atoms move from low to high concentration region in Si
 - Performed at high temperature to obtain speed
 - When wafer is cooled impurities are “frozen” in Si
 - Boron, arsenic, phosphorus are common dopants

Process Steps


- **Ion Implantation**
 - Ions are accelerated by electric field
 - Produces more accurate and reproducible profiles than diffusion
- **Chemical Vapor Deposition**
 - Used to deposit various materials such as Si_3N_4 on Si
- **Metallization**
 - Metal layer deposited via sputtering process
- **Photolithography**
 - Wafer is coated with photoresist
 - Mask selectively exposes some regions to UV light
 - High precision is required
- **Dicing & Packaging**
 - IC's are separated from wafer
 - Die attach and wire bonding

Step 1 – n-Well Diffusion




- **Diffusion Process**
 - Regions for diffusion are exposed after oxide is etched
 - Phosphorus diffuses faster than arsenic into substrate

Step 2 – Define Active Regions




- **Process**
 - Active regions are where transistors are to be placed
 - Use silicon nitride (Si_3N_4) to mask oxidation

Step 3 – Local Oxidation (LOCOS)



- **Process**
 - Thick field oxide appears in region between transistors
 - Field oxide isolate transistors
 - Allows interconnection layers to be routed to top


Step 4 – Gate Formation



- **Process**

- Most critical step in CMOS process
- Polysilicon layer is deposited and patterned
- Fine resolution produces short channel length


Step 5 – n+ Diffusion



- **Process**

- Photoresist protects p-MOSFET region
- Polysilicon gate acts as barrier for the implant
- Field oxide prevents formation of n+ from outside active region
- Polysilicon gate is self-aligned


Step 6 – p+ Diffusion



- **Process**

- Channel length is defined by gate mask alone → self alignment
- Polysilicon gate acts as barrier for the implant
- Gate protects channel region


Step 7 – Contact Holes



- **Process**

- CVD oxide deposited
- Photomask is used to define contact window opening
- Etch oxide with wet or dry process


Step 8 – Metallization



- **Process**

- Evaporate or sputter thin layer of aluminum
- Use masking to pattern interconnection
- Use CVD oxide for passivation as protective layer

CMOS Layout



n Well

Active region (LOCOS)



Poly 1 (poly-Si gate)

n+ diffusion

p+ diffusion

Contact hole

Metal 1



CMOS Layout

